Preparing Your Room





Avoid delays! Get your equipment room ready.

Checklist: Does your room have the following?

- ✓ The required power (110/120V) to support your new service
- ✓ Dedicated power outlets no more than 2 meters (~6 feet) from the space
- ✓ A temperature that does not rise above 78°F
- √ Ample lighting
- ✓ At least a 0.61m x 0.61m (2' x 2') space to add a cabinet, rack, or wall-mount if needed
- ✓ A 0.61m x 0.61m (2' x 2') backboard fire-rated plywood fastened to studs, and able to support 10 kilograms (22 pounds), **if needed**
- ✓ The backboard should be within 2 meters (~6 feet) of a dedicated power outlet.
- ✓ The circuit must terminate within 6 meters (~20 feet) of the wall-mounted equipment; the use of power strips is not permitted.
- ✓ The room is dust-free and contains proper ventilation